

SCALE BLASTER®

The healthy alternative to water softeners

SB-MAX

Installation & Operation Manual



Residential unit for large homes and/or very hard water areas
Indoor/Outdoor installation

IDENTIFY THE SB-MAX COMPONENTS

Your new **ScaleBlaster** SB-MAX unit includes the following components:

1.) One (1) SB-MAX power unit that works on 115VAC or 230VAC automatically. If 230VAC is desired, replace plug. This unit comes with a 5 foot power cord.



2.) Signal Cable (110') and five (5) nylon cable ties



3.) Warranty Card


4.) Extended Warranty Card

5.) Installation & operation manual

3.)



4.)



5.)



The ScaleBlaster unit can be installed on a horizontal or vertical Copper, PVC, CPVC and/or PEX pipe.

If a magnet will stick to your incoming water line, you have galvanized pipe. In this case, you will need to replace a small section of pipe, about 10-11 inches, with either pvc or copper pipe.

Before You Start Installing

Finding The Main Cold Water Pipe

The water shutoff valve is on the main cold water pipe. Install the **ScaleBlaster** unit on this pipe as close to where it comes into the house as possible. This will ensure that the outside spigots and kitchen are being treated.

Well Water Installation

For customers that are on a private well, the best place to install the **ScaleBlaster** unit is after the well's pressure tank. If that is not possible, the **ScaleBlaster** unit can be installed prior to the pressure tank.

Softener Loop

The **ScaleBlaster** unit can be installed on a softener loop. Installing on a softener loop gives treatment to all of the water that a softener would treat. Water to the kitchen faucet and outside spigots may not be treated when the **ScaleBlaster** unit is installed this way.

Find The Pipe Size


If you do not know the actual pipe size, place a ruler in front of the pipe and measure the outside diameter. Use **Table 1** to determine the size of the pipe. The actual pipe size is always rated by the inside dimensions of the pipe.

COPPER		PVC, CPVC & PEX	
Outside Diameter	Actual Size	Outside Diameter	Actual Size
5/8"	1/2"	.84"	1/2"
7/8"	3/4"	1.05"	3/4"
1 1/8"	1"	1.315"	1"
1 3/8"	1 1/4"	1.660"	1 1/4"
1 5/8"	1 1/2"	1.900"	1 1/2"
2 1/8"	2"	2.375"	2"

Table 1

A Tight Wrap Is Very Important

It is extremely important to the effectiveness of your **ScaleBlaster** unit that the signal cable wire be wrapped correctly. If there are any gaps between the wraps, your **ScaleBlaster** unit will not work to its full capacity.




Example of a properly wrapped pipe. No gaps or loose wire wrappings allowed!
See chart on pages 6 & 7 to wrap the coil and to determine the proper number of wraps.

LOCATION OF THE SB-MAX UNIT

- 1.) The most desirable place to install the unit is on the main water line that enters the house.
- 2.) The power unit should be mounted on a wall or other solid surface within five feet from an electrical outlet and within ten feet from where the pipe will be wrapped.
- 3.) Once the main water inlet pipe to the house is located, identify a section of pipe that is at least 12 inches straight and at least two feet away from any major electrical interference, example - an electric motor.

Installs on the incoming water supply line



Important! For best results, wrap signal cable on a straight section of pipe of 12" or more. Keep the signal cable as far away as possible from tees, elbows, couplings, valves and any curved pipe.



MOUNTING THE POWER UNIT


The unit can be mounted indoors or outdoors in an upright vertical position on a wall or other non-enclosed area. **NOTICE: If mounting the power unit outside, it must be kept out of the direct sunlight.** The installer must supply the mounting screws for the type of surface the unit will be mounted on.

Mount power unit on a solid surface (out of direct sunlight) using already installed mounting brackets.



INSTALLING THE SIGNAL CABLE

Insert the pre-stripped end of the signal cable into one of the two signal terminals and tighten. Follow instruction on how to wrap pipe with wire on next two pages (pages 6 & 7).




Twist down to see hole to put wire in, put stripped wire in hole (making sure the two bare wires do not touch) then twist up to tighten.

Wrapping the pipe with the ScaleBlaster Signal Cable

PVC, CPVC, or PEX PIPE INSTRUCTIONS


- 1.) Insert the pre-stripped end of the signal cable into one of the two signal terminals and tighten.
- 2.) Route the signal cable to the inlet pipe. Hold cable parallel and next to the pipe.
- 3.) Using one of the cable ties, secure the wire to the pipe. (**Figure A**)



- 4.) Wrap the loose end of the signal cable securely around the pipe - in any one direction – the proper number of turns as noted in **Chart A** below.


- 5.) Make sure the wraps are flush against one another, wrapped tightly and not overlapping. Continue until you reach the recommended number of wraps.

- 6.) Using a second cable tie at the end of the wrappings, secure the wire to the pipe, keeping all the wraps tight. (**Figure B**)



- 7.) With single coil wrapping around the pipe, a second one is now added.
- 8.) **YOU MUST KEEP THE SECOND WRAPPING IN THE SAME DIRECTION AS THE FIRST!** Wrap right over the top of the first layer continuing in the same wrapping direction as the first layer. This second layer must also be tight and touching the prior wrap. (**Figure C**)


Figure C



- 9.) Using a third cable tie at the end of the wrappings, secure the wire to the pipe, keeping all the wraps tight. (**Figure D**)

- 10.) Route the loose end of the signal cable back to the power box. Trim excess cable to length.

- 11.) Carefully strip the outer plastic shield from the end of the signal cable leaving 1/2" to 5/8" of bare cable. Twist the bare cable and insert the end in the other terminal post on the power box and tighten the receptacle post.



Never under wrap or over wrap the coil.

Chart A

Wrap Requirement PVC or PEX pipe

SB-MAX

Pipe Size	Layers / Wraps
3/4"	Double 80 wraps
1"	Double 55 wraps
1 1/4"	Double 40 wraps
1 1/2"	Double 34 wraps

COPPER PIPE INSTRUCTIONS

- 1.) Follow the same instructions in **steps of 1-9** for PVC, CPVC and PEX pipe, except use **CHART B** below to determine the number of wraps for copper pipe.
- 2.) Instead of a double coil wrapping around the pipe, a third one is added for copper pipe.
- 3.) **YOU MUST KEEP THE THIRD WRAPPING IN THE SAME DIRECTION AS THE FIRST AND SECOND!** Wrap right over the top of the second layer continuing in the same wrapping direction as the first and second layer. This third layer must also be tight and touching the prior wrap. **(Figure E)**




Figure E

- 4.) Wrap a fourth cable tie around the pipe and both wires. Pull the cable tie tight. **(Figure F)**




Figure F

- 5.) Follow same instructions in **steps 10-11** for PVC, CPVC and PEX pipe.

CHART B

Wrap Requirement COPPER pipe

SB-MAX

Pipe Size	Layers / Wraps
3/4"	Triple 70 wraps
1"	Triple 68 wraps
1 1/4"	Triple 62 wraps
1 1/2"	Triple 54 wraps

Never under wrap or over wrap the coil. Improper wrapping will cause the unit to overheat. This is for all types of pipe.

ACTIVATING THE SYSTEM

- 1.) Plug control box into electrical outlet after mounting the control box on the wall and wrapping the signal coil.
- 2.) The LED light on the front panel should light up.
- 3.) Operation of the **ScaleBlaster SB-MAX** system can be confirmed by observing the illumination of the LED indicator located on the face of the power unit. Power on - green light on far right side will stay lit **(Figure G)**. When pipe is wrapped and unit is turned on the far right light will stay lit and the other lights will oscillate back and forth **(Figure H)**.




Figure G




Figure H

MAINTENANCE

The best feature of the **ScaleBlaster SB-MAX** is that there is **NO MAINTENANCE REQUIRED**. No salt, batteries, moving parts or costly repairs. Just check the LED light for proper operation.

WARRANTY & EXTENDED WARRANTY

This unit comes with a five (5) year warranty to be free from defects in material and workmanship under normal use from the date of purchase. A five (5) year extended warranty is available on this unit at a very minimal cost.

120-DAY MONEY-BACK GUARANTEE

We are so sure you will be satisfied with **ScaleBlaster**, we are offering a 120-day money back guarantee from the date of purchase if you are not 100% satisfied with the product.

ENJOYING THE SCALEBLASTER SYSTEM

There is no maintenance with the **ScaleBlaster** unit itself! No bags of salt to haul around, wasted water or batteries to change. Best of all, you are protecting the environment!

Allow up to 90 days to realize the full effects. Initial descaling may make things worse for awhile, especially in the dishwasher and aerators. This is normal! Simply clean out the screens or aerators. With dishwashers, we recommend cutting back on soap usage (unless you have been using a water softener). In July of 2010, manufacturers of dishwasher soap detergents cut back on phosphates - resulting in an increase in spotting and cloudiness. We recommend using *Cascade Action Pacs with Dawn or Cascade All-in-one Action Pacs* for best cleaning results. Another product that works best is *Lemi Shine*. You may also add white vinegar in the rinse cycle.

After the first 90 days, we strongly recommend you drain out your water heater. You will be amazed at what **ScaleBlaster** has cleaned out of your pipes!



The healthy alternative to water softeners

Commercial & industrial models available for pipes up to 40"

Manufactured by



Established 1989



Phone: 800-756-7946 or 727-562-5186 • Fax: 727-562-5187

ScaleBlaster.com