

3

Secure hoses to filter and DosaCart:

A. Insert
hose onto filter
barb. Secure with
clamp.



B. Secure outgoing
hose with
zip tie to
eye hook.



ASSEMBLY INSTRUCTIONS

D45 Quick Hook-Up Kit

Portable Fertilizer System - Part #: HSPK D45
Fits D45 (20 GPM Model)

(Dosatron Unit, Quick Hook-Up Kit and Cart Sold Separately)



2090 Sunnydale Blvd. • Clearwater, FL 33765 • 727-443-5404
800-523-8499 • www.dosatronusa.com

2009-03 2009-104-HORT023

Customer Service and Technical Support

1 - 8 0 0 - 5 2 3 - 8 4 9 9

1 Attach filter to DosaCart:

A. Unscrew the two (2) screws from the corners of the black plate on the back of the DosaCart.



B. Remove plate and attach the Dosatron unit bracket for your unit on the same side as the eyebolts.



C. Attach the 200 mesh/80 micron filter to the back of the plate, bottom left. Re-attach black plate back onto your DosaCart.



2 Attach Dosatron unit:

A. Assemble the Quick Hook-Up Kit with unit (see *Quick Hook-Up Kit assembly instructions that came with kit*).



B. Attach Dosatron unit and Quick Hook-Up Kit onto unit bracket.

